



IMPORTANT

The solution with pilot wire also allows creating intermediate areas by grouping several rooms, or a whole floor or building.

The following accessories are required for centralisation:

- D600V diode to be wired on each module so as to prevent local control circulation on the pilot wire.
- R12M interface, to be wired behind all twin buttons.

DAILY SCHEDULER

Daily opening and closing times can be scheduled. To do so, at the DESIRED TIME, make:

- 8 presses to store the closing time
- 9 presses to store the opening time
- 7 presses to store the intermediate position time

NOTE: In case of power supply failure, MVR500E deletes all scheduled values; it will thus be necessary to repeat the configuration to the desired times. As an alternative, you can connect an external time switch or a twilight sensor through accessory CVI34 (Part no. 5454806).