

Shutter centralisation with different automations

AUTOMATIC CONTACT




When contact closes, shutter opens.
When contact opens, shutter closes.


L BP



When contact closes (*), shutter opens.
When contact opens, shutter does not move.



When contact closes (*), shutter closes.
When contact opens, shutter does not move.



(*) the contact must remain closed for at least 1 s.

IMPORTANT

Installer configuration enabling: **23 short presses**
 Installer configuration lock: **21 short presses**

AUTOMATIC CONTACT

Based on wiring modes, several operating modes are available: see box at the side.

Automatic contact: timer, twilight sensor, anemometer, presence detector, alarm, etc.

